



RESORT COMFORT BASE™ VOICE COMMAND SETUP GUIDE



AMAZON ALEXA DEVICES

***Make sure your Alexa device is set to a 2.4G WiFi connection, if you have not done so already follow these steps.**

Open the Alexa app > Go to Settings > Select the Alexa device that will pair with your bed > Select Change WiFi Network & follow prompts.

1 Open the Amazon Alexa App.

Search for "Cariloha Comfort Base skill" in the Alexa Skill Store and enable it.

2 Enter email & password.

EMAIL: same email as used in the Cariloha Comfort Base App

PASSWORD: same password as used in the Cariloha Comfort Base App

3

Alexa and the WiFi adapter need to be set to the same LAN and use the same WiFi. First, you need to give the command: **"Alexa, ask my base to find device."** Once your bed finds and connects to your device move to the next page.

***SPLIT SETS WHO WANT THEIR BEDS TO MOVE INDEPENDANTLY PLEASE NOTE THE FOLLOWING:**

You will need: 2 Amazon accounts, 2 Alexa devices, 2 WiFi adapters and to repeat the steps for Alexa voice command setup. You also need to name your Alexa devices a different name, such as "Alexa" and "Echo".



GOOGLE HOME DEVICES

***Make sure your Google Home device is set to a 2.4G WiFi connection, if you have not done so already follow these steps.**

Open the Google Home app > Select the Devices button in the top right hand corner > Select the Google Home device that will pair with your bed > Select Settings and make sure your router is broadcasting a 2.4G signal is selected.

1 Open the Google Assistant App.

Search for Cariloha Comfort Base action and select "Talk to Power Base". Then select "Link".

2 Enter email & password and select app.

EMAIL: same email as used in the Cariloha Comfort Base App

PASSWORD: same password as used in the Cariloha Comfort Base App

3

Once your bed finds and connects to your device, use the invocation phrase **"Hey Google, Talk to Power Base"** to start the bed action. Then move on to the next page.

***SPLIT SETS WHO WANT THEIR BEDS TO MOVE INDEPENDANTLY PLEASE NOTE THE FOLLOWING:**

(GOOGLE HOME IS NOT COMPATIBLE AT THIS TIME)



VOICE COMMANDS



Raise Head:

"...raise the head"
"...raise head"
"...put the head up"

Lower Head:

"...lower the head"
"...put the head down"
"...move the head down"

Raise Foot/Feet:

"...raise the foot"
"...raise my feet up"
"...put the feet up"

Lower Foot/Feet:

"...lower the foot"
"...take the foot down"
"...move my foot down"

Dual Massage:

"...start dual massage"
"...start dual massaging"

Start Head Massage:

"...start head massage"
"...start the head massage"

Start Foot Massage:

"...start foot massage"
"...start the foot massage"

Turn Off Massage:

"...turn off massage"
"...stop massaging"
"...turn off the massaging"

Increase Head Massage Intensity:

"...increase head massage"
"...turn up the head massage"
"...increase the head massage intensity"

Decrease Head Massage Intensity:

"...decrease head massage"
"...turn up the head massage"
"...decrease head massage intensity"

Increase Foot Massage Intensity:

"...increase foot massage"
"...turn up the foot massage"
"...increase foot massage intensity"

Decrease Foot Massage Intensity:

"...decrease foot massage"
"...turn down the foot massage"
"...decrease foot massage intensity"

Zero G:

"...go to Zero G"
"...put me in Zero G"
"...Zero Gravity"

Flat:

"...go to the flat position"
"...flatten"
"...go flat"

Raise Pillow Tilt:

"...raise the tilt"
"...increase pillow tilt"
"...raise pillow tilt"

Lower Pillow Tilt:

"...lower the tilt"
"...decrease pillow tilt"
"...lower pillow tilt down"

Preset Button 1:

"...go to preset one"
"...go to the preset one position"
"...take me to the preset one position"

Preset Button 2:

"...go to preset two"
"...go to the preset two position"
"...take me to the preset two position"

Anti-snore:

"...go to anti-snore"
"...anti-snore"
"...go to the anti-snore position"